


FREEMOTION[®]

u 10.9b

Model No. FMEX82418.0

Serial No. _____


Write the serial number in the space above for reference.



USER'S MANUAL

QUESTIONS?

If you have questions, or if parts are damaged or missing, please see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.



▲ CAUTION

Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.

TABLE OF CONTENTS

WARNING DECAL PLACEMENT 2

IMPORTANT PRECAUTIONS..... 3

BEFORE YOU BEGIN..... 4

PART IDENTIFICATION CHART..... 5

ASSEMBLY..... 6

HOW TO UPGRADE THE CONSOLE 14

HOW TO USE THE EXERCISE BIKE..... 15

COMPLIANCE INFORMATION..... 24

MAINTENANCE AND TROUBLESHOOTING 25

EXERCISE GUIDELINES 26

PART LIST..... 28


EXPLODED DRAWING..... 30

HOW TO CONTACT CUSTOMER CARE..... Back Cover

LIMITED WARRANTY..... Back Cover


WARNING DECAL PLACEMENT

This drawing shows the location(s) of the warning decal(s). **If a decal is missing or illegible, see the front cover of this manual and request a free replacement decal. Apply the decal in the location shown.** Note: The decal(s) may not be shown at actual size.



WARNING

- Misuse of this machine may result in serious injury.
- Read user's manual prior to use and follow all warnings and instructions.
- Do not allow children on or around machine.
- Pedals continue to spin when you stop pedaling.
- Spinning pedals can cause injury.
- Reduce pedal speed in a controlled manner.
- User weight must not exceed 400 lbs / 181 kgs.
- This product should always be used on a level surface.
- This product is not intended for therapeutic use.
- Replace label if damaged, illegible, or removed.



FREEMOTION and IFIT are registered trademarks of ICON Health & Fitness, Inc. App Store is a trademark of Apple Inc., registered in the U.S. and other countries. Android and Google Play are trademarks of Google LLC. The Bluetooth® word mark and logos are registered trademarks of Bluetooth SIG, Inc. and are used under license. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. POLAR is a registered trademark of Polar Electro Oy.

IMPORTANT PRECAUTIONS

⚠️ WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons, read all important precautions and instructions in this manual and all warnings on your exercise bike before using your exercise bike. Freemotion Fitness assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

1. It is the responsibility of the owner to ensure that all users of the exercise bike are adequately informed of all precautions.
2. Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
3. Use the exercise bike only as described in this manual.
4. Keep the exercise bike indoors, away from moisture and dust. Do not put the exercise bike in a garage or covered patio, or near water.
5. Place the exercise bike on a level surface with at least 2 ft. (0.6 m) of clearance around the exercise bike. To protect the floor or carpet from damage, place a mat under the exercise bike.
6. Inspect and properly tighten all parts each time the exercise bike is used. Replace any worn parts immediately.
7. Keep children under age 13 and pets away from the exercise bike at all times.
8. Wear appropriate clothes while exercising; do not wear loose clothes that could become caught on the exercise bike. Always wear athletic shoes for foot protection.
9. The exercise bike should not be used by persons weighing more than 400 lbs. (181 kg).
10. Be careful when mounting and dismounting the exercise bike.
11. The heart rate monitor is not a medical device. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining heart rate trends in general.
12. Always keep your back straight while using the exercise bike; do not arch your back.
13. Over exercising may result in serious injury or death. If you feel faint, if you become short of breath, or if you experience pain while exercising, stop immediately and cool down.


BEFORE YOU BEGIN

Thank you for selecting the revolutionary FREEMOTION® U 10.9 B exercise bike. The U 10.9 B exercise bike provides an impressive selection of features designed to make your workouts more effective and enjoyable.

For your benefit, read this manual carefully before you use the exercise bike. If you have questions after











reading this manual, please see the back cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number and the location of the serial number decal are shown on the front cover of this manual.

Before reading further, please familiarize yourself with the parts that are labeled in the drawing below.



PART IDENTIFICATION CHART

Use the drawings below to identify the small parts needed for assembly. The number in parentheses below each drawing is the key number of the part, from the PART LIST near the end of this manual. The number following the key number is the quantity needed for assembly. **Note: If a part is not in the hardware kit, check to see if it has been preassembled. Extra parts may be included.**

			
M8 x 12mm Washer (108)-4	M8 Split Washer (45)-4	M8 x 16mm Washer (110)-7	
			
M4 x 12mm Self-tapping Screw (118)-4	M4 x 16mm Screw (56)-2	M5 x 8mm Screw (89)-4	M5 x 12mm Screw (111)-20
			
M8 x 25mm Patch Screw (44)-4	M8 x 20mm Cap Screw (107)-4	M8 x 25mm Cap Screw (109)-3	

ASSEMBLY

- Assembly requires two persons.
- Place all parts in a cleared area and remove the packing materials. Do not dispose of the packing materials until you finish all assembly steps.
- If a part is not in the hardware kit, check to see if it has been preassembled.
- Left parts are marked “L” or “Left” and right parts are marked “R” or “Right.”
- To identify small parts, see page 5.

- The following tools (not included) are required for assembly:

one adjustable wrench



one Phillips screwdriver




a set of metric hex keys




Assembly may be easier if you have a set of wrenches. To avoid damaging parts, do not use power tools.

1. Identify the Rear Stabilizer (114), which does not have wheels, and orient it as shown.

Attach the Rear Stabilizer (114) to the Frame (1) with two M8 x 25mm Patch Screws (44), two M8 Split Washers (45), and two M8 x 16mm Washers (110).



- Attach the Front Stabilizer (19) to the Frame (1) with two M8 x 25mm Patch Screws (44), two M8 Split Washers (45), and two M8 x 16mm Washers (110).




- Have a second person hold the Upright (66) near the Frame (1).

See the inset drawing. Connect the Upper Main Wire (42) to the Lower Main Wire (69), connect the Upper Power Wire (63) to the Lower Power Wire (64), and connect the Upper TV Coaxial Cable (68) to the Lower TV Coaxial Cable (67).

See the inset drawing. Locate the covers (A, B) on the Lower TV Coaxial Cable (67) and on the Upper TV Coaxial Cable (68). Slide the covers together and **push the small cover (A) into the large cover (B).**


Then, insert the excess wire into the Upright (66).

Tip: Avoid pinching the wires. Attach the Upright (66) to the Frame (1) with four M8 x 20mm Cap Screws (107) and four M8 x 12mm Washers (108); **start all the Cap Screws, and then tighten them.**




4. Hold the Left Front Shield (101) against the left side of the Frame (1). Insert the left side of the Wiring Plate (18) into the Left Front Shield.

Attach the Left Front Shield (101) with two M4 x 12mm Self-tapping Screws (118); **do not fully tighten the Self-tapping Screws yet.**




5. Hold the Right Front Shield (102) against the right side of the Frame (1). Insert the right side of the Wiring Plate (18) into the Right Front Shield.

Attach the Right Front Shield (102) with two M4 x 12mm Self-tapping Screws (118) and two M4 x 16mm Screws (56); **do not fully tighten the Screws yet.**




6. **Tip: Avoid pinching the wires.** Attach the Wiring Plate (18) to the Frame (1) with four M5 x 12mm Screws (111); **start all the Screws, and then tighten them.**




7. Attach the Front Shield Cover (103) to the Right and Left Front Shields (101, 102) with four M5 x 12mm Screws (111); **start all the Screws, and then tighten them.**

See assembly steps 4 and 5. Tighten the M4 x 12mm Self-tapping Screws (118) and the M4 x 16mm Screws (56).




8. While a second person holds the Handlebar (70) near the Upright (66), route the wires (C) in the Handlebar through the Upright as shown.

Tip: Avoid pinching the wires. Attach the Handlebar (70) to the Upright (66) with three M8 x 25mm Cap Screws (109) and three M8 x 16mm Washers (110); **start all the Cap Screws, and then tighten them.**




9. While a second person holds the Console (106) near the Upright (66), connect the wires (D) on the Console to the matching wires (E) in the Upright.

Note: The indicated wires (F) will not be used unless you purchase the optional digital TV (see HOW TO UPGRADE THE CONSOLE on page 14).



10. Locate the two couplers (G, H) in the back of the Console (106). Insert the wires (E) and the two couplers downward into the Upright (66).

Tip: Avoid pinching the wires. Attach the Console (106) to the Upright (66) with four M5 x 8mm Screws (89); **start all the Screws, and then tighten them.**



If you purchased the optional MYE receiver to set up a wall of TVs, go to step 11 to install the receiver.

If you did not purchase the optional MYE receiver, go to step 12. To order the optional MYE receiver, see the back cover of this manual.


11. **See the upper drawing.** Look in the Upright (66) and locate the coupler (G) that has a wire labeled "In" (I) and a wire labeled "Out" (J).

See the inset drawing. Unplug the wire labeled "In" (I) and the wire labeled "Out" (J) from the coupler (G), and discard the coupler.

See the lower drawing. Then, plug the wire labeled "In" (I) into the "In" port on the receiver (K), and plug the wire labeled "Out" (J) into the "Out" port on the receiver.


Next, peel the backing (L) off the receiver (K), and press the receiver onto the Upright (66).

Follow the instructions included with the MYE programmer to program the receiver.




12. **Tip: To avoid pinching the wires, make sure that the wires (C) from the Handlebar (70) are arranged as shown.**


Attach the Accessory Tray (99) to the Upright (66) with two M5 x 12mm Screws (111); **start both Screws, and then tighten them.**




13. **Tip: Avoid pinching the wires.** Attach the Rear Upright Cover (100) to the Accessory Tray (99) and the Upright (66) with four M5 x 12mm Screws (111); **start all the Screws, and then tighten them.**



14. **Tip: Avoid pinching the wires.** Attach the Front Upright Cover (98) to the Upright (66) with six M5 x 12mm Screw (111); **start all the Screws, and then tighten them.**




15. Pull the Adjustment Handle (35) upward, insert the Seat Post (84) into the Frame (1), and then release the Adjustment Handle. **Move the Seat Post upward or downward slightly to make sure that it is engaged in the Frame.**



16. Identify the right Pedal (17). Using an adjustable wrench, **firmly tighten** the right Pedal **clockwise** into the Right Crank Arm (9).

Firmly tighten the left Pedal (not shown) counterclockwise into the Left Crank Arm (not shown). IMPORTANT: You must turn the left Pedal counterclockwise to attach it.



17. **After the exercise bike is assembled, inspect it to make sure that it is assembled correctly and that it functions properly. Make sure that all parts are properly tightened before you use the exercise bike.** Extra parts may be included. Place a mat under the exercise bike to protect the floor or carpet.

HOW TO UPGRADE THE CONSOLE

Your console has been preconfigured to operate with an optional digital TV.

To learn about the features of the basic console, see page 16. To learn about the features of the digital TV, see the user's manual included with the digital TV. The basic console has no television capabilities.

To upgrade your console to include a digital TV whenever you choose, please see the back cover of this manual.


HOW TO USE THE EXERCISE BIKE

HOW TO PLUG IN THE INCLUDED POWER ADAPTER

The exercise bike can be used with or without the included power adapter. When the exercise bike is used without the power adapter, power will be supplied by an internal generator.

IMPORTANT: If the exercise bike has been exposed to cold temperatures, allow it to warm to room temperature before you plug in the power adapter. If you do not do this, you may damage the console displays or other electronic components.

Plug the power adapter into the **lower** power receptacle (A) on the frame of the exercise bike. Then, plug the power adapter into an appropriate outlet that is properly installed in accordance with all local codes and ordinances.




HOW TO PLUG IN THE DIGITAL TV POWER ADAPTER

If the exercise bike has an optional digital TV, the power adapter included with the digital TV must be used for the digital TV to operate.

IMPORTANT: If the exercise bike has been exposed to cold temperatures, allow it to warm to room temperature before you plug in the power adapter. If you do not do this, you may damage the console displays or other electronic components.


Plug the power adapter for the optional digital TV into the **upper** digital TV power receptacle (B) on the frame of the exercise bike. Then, plug the power adapter into an appropriate outlet that is properly installed in accordance with all local codes and ordinances.



HOW TO CONNECT A COAXIAL CABLE TO THE EXERCISE BIKE

If the exercise bike has an optional digital TV, a coaxial cable must be connected to the exercise bike for cable or over-the-air TV stations to be viewed.

Locate the coaxial cable terminal (C) on the frame of the exercise bike. Connect the coaxial cable to the coaxial cable terminal. Route the coaxial cable so that it will not be pinched or crushed by the exercise bike.




A satellite receiver, VCR, or DVD player can also be connected to the exercise bike. Connect a coaxial cable from the coaxial output on your equipment (usually labeled TV OUT or RF OUT) to the coaxial cable terminal (C) on the frame of the exercise bike.

Note: Audio/video equipment without coaxial outputs may be able to be connected directly to the optional digital TV; the optional digital TV has a variety of input receptacles.

WARRANTY INFORMATION

The warranty for this product does not cover damage or equipment failure caused by electric wiring not in compliance with electrical codes or the specifications in this manual, or failure to provide reasonable and necessary maintenance as outlined in this manual. Any failure or damage caused by unauthorized service; misuse; accident; negligence; improper assembly or installation; debris resulting from any destruction activities in the product's environment; rust or corrosion as a result of the product's location; alterations or modifications without written authorization; or failure on your part to use, operate, and maintain the product as set forth in this manual will void the warranty.

All terms of the warranty are void if this product is moved beyond the continental borders of the United States of America (excluding Alaska, Hawaii, and Canada) and are then subject to the terms provided by that country's local authorized Freemotion Fitness, Inc. representative.



FEATURES OF THE CONSOLE

The console offers an impressive array of features designed to make your workouts more effective and enjoyable.

The console features a selection of onboard programs that automatically control the resistance of the pedals while guiding you through effective exercise sessions.

When you use the quick start mode, you can change the resistance of the pedals with the touch of a button.

As you exercise, the console will display instant exercise feedback. You can even measure your heart rate using the handgrip heart rate monitor or a Polar®-compatible chest heart rate monitor.

You can even connect your tablet to the console and use the iFit®-Smart Cardio Equipment app to record and track your workout information.

You can also use the charging port on the console to charge your USB-compatible device while you exercise.

To activate the console, see page 17. **To turn off the console**, see page 17. **To use the charging port**, see page 17.

To use the quick start mode, see page 18. **To use an onboard program**, see page 20. **To connect your tablet to the console**, see page 22. **To change console settings**, see page 22.

Note: If there is a sheet of plastic on the display, remove the plastic.

Note: The console can display speed and distance in either miles and miles per hour or kilometers and kilometers per hour. To find which unit of measurement is selected, see HOW TO CHANGE CONSOLE SETTINGS on page 22.

HOW TO ACTIVATE THE CONSOLE

If the exercise bike has a basic console, it can be used with or without the power adapter.

To use the exercise bike without the power adapter, simply begin pedaling. The displays and indicators will light and the words SELECT WORKOUT OR PRESS START TO BEGIN will scroll across the message banner.

While you pedal, power will be supplied by an internal generator; remember to continue pedaling while you use the exercise bike.

If the exercise bike has an optional digital TV, the power adapter must be used for the digital TV to be operated. See HOW PLUG IN THE DIGITAL TV POWER ADAPTER on page 15.

When the power adapter is plugged in, the displays and indicators will light and the words SELECT WORKOUT OR PRESS START TO BEGIN will scroll across the message banner.

HOW TO TURN OFF THE CONSOLE

If the pedals are not moved and no buttons are pressed for a short while, the console will turn off automatically.

If the exercise bike is being used with the power adapter, unplug the power adapter when you are finished exercising. **IMPORTANT: If you do not do this, the electrical components on the exercise bike may wear prematurely.**

HOW TO USE THE CHARGING PORT

The console features a charging port that you can use to charge USB-compatible devices, such as tablets and smartphones, while you exercise.

To use the charging port, plug a USB charging cable (not included) into the charging port on the front of the console and into the receptacle on your device; **make sure that the USB charging cable is fully plugged in.** Note: The charging port cannot be used to view or transfer data or to play music through the console sound system.

HOW TO USE THE QUICK START MODE

1. Turn on the console.

See HOW TO ACTIVATE THE CONSOLE on page 17.

2. Select the quick start mode.

To select the quick start mode, press the Start button.

3. Change the resistance of the pedals as desired.

As you pedal, you can change the resistance of the pedals. To change the resistance, press the Resistance increase and decrease buttons on the console or on the handlebars.

Note: After you press a button, it will take a moment for the pedals to reach the selected resistance level.

4. Follow your progress.

The displays can show the following workout information:

Matrix—This display will show a profile of the resistance levels of the workout or program.

Message Banner—This display will show a variety of workout information and scrolling text messages.

Heart Rate—This display will show your heart rate when you use the handgrip heart rate monitor or a Polar-compatible chest heart rate monitor (see step 5).

Resistance—This display will show the resistance level of the pedals.

Time/Pace—This display will show the workout time and your pedaling pace in minutes per mile or minutes per kilometer in a repeating cycle (scan mode).

To select either the time display or the pace display for continuous display (priority mode), press the left Mode button repeatedly until a solid light appears next to the desired display. To return to the scan mode, press the left Mode button until a flashing light appears next to the displays in a repeating cycle.

When the quick start mode is selected, the time display will show the elapsed time. When a program is selected, the time display will show the time remaining in the program.

Note: The console can display distance in either miles or kilometers. To find which unit of measurement is selected, see HOW TO CHANGE CONSOLE SETTINGS on page 22.

Cals/Watts—This display will show the approximate number of calories you have burned and your power output in watts in a repeating cycle (scan mode).

To select either the calories display or the watts display for continuous display (priority mode), press the center Mode button repeatedly until a solid light appears next to the desired display. To return to the scan mode, press the center Mode button until a flashing light appears next to the displays in a repeating cycle.

Dist/Speed/RPM—This display will show the distance that you have pedaled in miles or kilometers, your pedaling speed in miles or kilometers per hour, and your pedaling speed in revolutions per minute (RPM) in a repeating cycle (scan mode).

To select the distance, speed, or RPM display for continuous display (priority mode), press the right Mode button repeatedly until a solid light appears next to the desired display. To return to the scan mode, press the right Mode button until a flashing light appears next to the displays in a repeating cycle.

Note: The console can display speed in either miles per hour or kilometers per hour. To find which unit of measurement is selected, see HOW TO CHANGE CONSOLE SETTINGS on page 22.

5. Measure your heart rate if desired.


You can use the handgrip heart rate monitor or you can wear a Polar-compatible chest heart rate monitor (not included) to measure your heart rate.

IMPORTANT: If you use both heart rate monitors at the same time, the console will not display your heart rate accurately.

To use the handgrip heart rate monitor, follow the instructions below.

If there are sheets of plastic on the metal contacts (A) on the handgrip heart rate monitor, remove the plastic.

To measure your heart rate, hold the handgrip heart rate monitor with your palms resting against the contacts on the upper body arms or the contacts on the handlebars. **Avoid moving your hands or gripping the contacts tightly.**



When your pulse is detected, your heart rate will be shown in the display. For the most accurate heart rate reading, hold the contacts for at least 15 seconds.

If the display does not show your heart rate, make sure that your hands are positioned as described. Be careful not to move your hands excessively or to squeeze the contacts tightly. For optimal performance, clean the contacts using a soft cloth; **never use alcohol, abrasives, or chemicals to clean the contacts.**

6. Pause the workout if desired.

To pause the workout, press the Stop button.

Note: If the pedals are not moved and no buttons are pressed for a short while, the console will exit the quick start mode or the program.

To resume the workout, press the Start button.

7. End the workout and view the workout summary.

When you are finished exercising, press the Stop button.

A workout summary will appear in the message banner.

8. Exit the workout summary.

To exit the workout summary, press the Stop button twice.

Note: After a short while, the console will exit the workout summary automatically.

9. Turn off the console.

See HOW TO TURN OFF THE CONSOLE on page 17.

HOW TO USE AN ONBOARD PROGRAM

1. Turn on the console.

See HOW TO ACTIVATE THE CONSOLE on page 17.

2. Select an onboard program.

To select an onboard program, press the Heart Rate, Weight Loss, Speed Interval, Watts Training, Race Training, or Hill Climb button repeatedly until the desired program appears in the displays.

The message banner will show the name of the program and other details about the program. The matrix will show the profile of the program.

3. Enter your weight.

To enter your weight, press the Weight increase and decrease buttons.

4. Enter your age.

To enter your age, press the Age increase and decrease buttons.

5. Begin exercising.

Press the Start button and begin pedaling to begin the program.

Heart Rate Program—Each heart rate program is divided into segments. A target heart rate is programmed for each segment. During the program, the profile in the matrix will show your progress. The flashing segment of the profile represents the current segment of the program. The height of the flashing segment indicates the resistance level for the current segment.

During the program, the console will regularly compare your actual heart rate with the target heart rate. To keep your actual heart rate near the target heart rate, the console will automatically adjust the resistance of the pedals and prompt you to increase or decrease your pedaling speed. **Keep your pedaling speed near the target speed shown in the message banner.**

Note: The target heart rates are percentages of your maximum heart rate. Your maximum heart rate is estimated by subtracting your age from 220. For example, if you are 30 years old, your estimated maximum heart rate is 190 beats per minute ($220 - 30 = 190$). Therefore, if you are 30 years old, a target heart rate setting of 60 percent is equal to 114 beats per minute (60 percent of 190 is 114). To determine a target heart rate that is suitable for you, consult your physician or a physician-recommended source.

For the most accurate heart rate readings, it is recommended that you wear a Polar-compatible chest heart rate monitor while using the heart rate program. You can also hold the handgrip heart rate monitor during the heart rate program (see step 5 on page 19).

IMPORTANT: The target heart rate is intended only to provide motivation. Make sure to exercise at an intensity level that is comfortable for you.

The program will continue in this way until the last segment ends.

Weight Loss, Speed Interval, and Hill Climb Programs—Each program is divided into segments. One resistance level and one target speed are programmed for each segment. Note: The same resistance level and/or target speed may be programmed for consecutive segments.

During the program, the profile in the matrix will show your progress. The flashing segment of the profile represents the current segment of the program. The height of the flashing segment indicates the resistance level for the current segment.

If the resistance level is too high or too low, you can manually override the resistance level by pressing the Resistance increase and decrease buttons.

The console will prompt you to increase or decrease your pedaling speed. **Keep your pedaling speed near the target speed shown in the message banner.**

IMPORTANT: The target speed is intended only to provide motivation. Make sure to exercise at an intensity level that is comfortable for you.

If the resistance level is too high or too low, you can manually override the resistance level by pressing the Resistance increase and decrease buttons. **IMPORTANT: The resistance level will automatically adjust at the end of each segment.**

The program will continue in this way until the last segment ends.

Watts Training Program—Each program is divided into segments. A watts target is programmed for each segment. During the program, the profile in the matrix will show your progress. The flashing segment of the profile represents the current segment of the program. The height of the flashing segment indicates the resistance level for the current segment.

To keep your actual watts output near the watts target, the console will automatically adjust the resistance of the pedals and prompt you to increase or decrease your pedaling speed. **Increase or decrease your pedaling speed to keep your actual watts output near the watts target shown in the message banner.**

IMPORTANT: The watts target is intended only to provide motivation. Make sure to exercise at an intensity level that is comfortable for you.

If the resistance level is too high or too low, you can manually override the resistance level by pressing the Resistance increase and decrease buttons. **IMPORTANT: The resistance level will automatically adjust at the end of each segment.**

The program will continue in this way until the last segment ends.

Race Training Program—Each program is divided into segments. During the program, the profile in the matrix will show your progress. The flashing segment of the profile represents the current segment of the program. The height of the flashing segment indicates the resistance level for the current segment.

As you exercise, change the resistance of the pedals as desired (see step 3 on page 18). The display will count down the distance you have pedaled.

The program will continue in this way until the last segment ends.

6. Follow your progress.

See step 4 on page 18.

7. Measure your heart rate if desired.

See step 5 on page 19.

8. Pause the program if desired.

See step 6 on page 19.

9. End the program and view the workout summary.

See step 7 on page 19.

10. Exit the workout summary.

See step 8 on page 19.

11. Turn off the console.

See HOW TO TURN OFF THE CONSOLE on page 17.

HOW TO CONNECT YOUR TABLET TO THE CONSOLE

The console supports Bluetooth connections to tablets via the iFit–Smart Cardio Equipment app. Note: Other Bluetooth connections are not supported.

1. Download and install the iFit–Smart Cardio Equipment app on your tablet.

On your iOS® or Android™ tablet, open the App StoreSM or the Google Play™ store, search for the free iFit–Smart Cardio Equipment app, and then install the app on your tablet. **Make sure that the Bluetooth option is enabled on your tablet.**

Then, open the iFit–Smart Cardio Equipment app and follow the instructions to set up an iFit account and customize settings.

2. Connect your tablet to the console.

Press the iFit Sync button on the console; the console will enter pairing mode, a pairing number will appear in the display, and the LED on the console will turn red.

Follow the instructions in the iFit–Smart Cardio Equipment app to connect your tablet to the console. After 30 seconds, the console will exit pairing mode and the LED on the console will turn off.

After your tablet is connected to the console, select the quick start mode or an onboard workout and press the Start button. Make sure to press the Start button within 60 seconds of connecting your tablet to the console or your tablet will be automatically disconnected.

Note: If you are not able to connect your tablet to the console during the 30-second pairing mode or if you are not able to press the Start button within 60 seconds of connecting your tablet to the console, press the iFit Sync button and repeat this step.

3. Record and track your workout information.

Follow the instructions in the iFit–Smart Cardio Equipment app to record and track your workout information.

4. Disconnect your tablet from the console if desired.

To disconnect your tablet from the console, first select the disconnect option in the iFit–Smart Cardio Equipment app. Then, press and hold the iFit Sync button on the console.

HOW TO CHANGE CONSOLE SETTINGS

1. Turn on the console.

See HOW TO ACTIVATE THE CONSOLE on page 17.

2. Select the settings mode.

To select the settings mode, press and hold the left Mode button.

3. Navigate the settings mode.

While the settings mode is selected, the display will show several optional screens. Press the Stop button repeatedly to select the desired optional screen.

The message banner will show instructions for the selected screen. **Make sure to follow the instructions shown in the message banner.**

4. Change settings as desired.

Units—The currently selected unit of measurement will appear in the message banner. To change the unit of measurement, press the center Mode button repeatedly. To view distance in miles, select ENGLISH. To view distance in kilometers, select METRIC.

Display Test—This option is intended to be used by service technicians.

Button Test—This option is intended to be used by service technicians to identify whether a certain button is working correctly.

Software Version Number—The software version number will appear in the message banner.

Total Time and Total Distance—The total number of hours that the exercise bike has been used and the total distance that the exercise bike has been pedaled will appear in the message banner.

CSAFE Login—Press the center Mode button repeatedly to enable or disable the CSAFE login functionality.

Pause Timeout—The selected pause time will appear in the message banner. When the console is paused, it will exit the workout or program after the entered number of seconds if the pedals do not move and no buttons are pressed. To change the pause timeout, press the Age increase and decrease buttons.

Idle Timeout—The selected idle time will appear in the message banner. When the console is idle, it will turn off after the entered number of seconds if the pedals do not move and no buttons are pressed. To change the idle timeout, press the Age increase and decrease buttons.

TV Setup—This option is used to set up an optional digital TV (see HOW TO UPGRADE the console on page 24). When this option is selected, the buttons on the console are programmed to access various menus and options on the optional digital TV as described below.

Center Mode button—Press this button to select the digital TV setup menu.

Chan increase and decrease buttons—Press these buttons to navigate up and down in the digital TV menus.

Vol increase and decrease buttons—Press these buttons to navigate right and left in the digital TV menus.

Enter button/right Mode button—Press these buttons to make a selection.

Left Mode button—Press this button to select a TV source.

Start button—Press this button to select the digit 0.

Heart Rate button—Press this button to select the digit 1.

Weight Loss button—Press this button to select the digit 2.

Speed Interval button—Press this button to select the digit 3.

Watts Training button—Press this button to select the digit 4.

Race Training button—Press this button to select the digit 5.

Hill Climb button—Press this button to select the digit 6.

Decrease button next to Enter button—Press this button to select the digit 7.

Increase button next to Enter button—Press this button to select the digit 8.

iFit Sync button—Press this button to select the digit 9.

For more information, see the user's manual included with the optional digital TV.

Language—The selected language will appear in the message banner. The console will display text messages in the selected language. To select a language, press the center Mode button repeatedly.

Bluetooth Low Energy—Press the center Mode button repeatedly to enable or disable the Bluetooth Low Energy functionality.

5. Exit the settings mode.

Press the Stop button to exit the settings mode.

COMPLIANCE INFORMATION

UNITED STATES

FCC Statement. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION: To assure continued compliance, use only shielded interface cables when connecting to computer or peripheral devices. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

CANADA

IC Statement. This Class B digital device complies with Canadian ICES-003. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MAINTENANCE AND TROUBLESHOOTING

MAINTENANCE

Inspect and tighten all parts of the exercise bike regularly. Replace any worn parts immediately.

To clean the exercise bike, use a damp cloth and a small amount of mild soap. **IMPORTANT: To avoid damage to the console, keep liquids away from the console and keep the console out of direct sunlight.**

CONSOLE TROUBLESHOOTING

If the console does not display your heart rate when you hold the handgrip heart rate monitor, or if the displayed heart rate appears to be too high or too low, see step 5 on page 19.

If a replacement power adapter is needed, call the telephone number on the cover of this manual. IMPORTANT: To avoid damaging the console, use only a manufacturer-supplied regulated power adapter.

EXERCISE GUIDELINES

⚠️ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.

The heart rate monitor is not a medical device. Various factors may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining heart rate trends in general.

These guidelines will help you to plan your exercise program. For detailed exercise information, obtain a reputable book or consult your physician. Remember, proper nutrition and adequate rest are essential for successful results.

EXERCISE INTENSITY

Whether your goal is to burn fat or to strengthen your cardiovascular system, exercising at the proper intensity is the key to achieving results. You can use your heart rate as a guide to find the proper intensity level. The chart below shows recommended heart rates for fat burning and aerobic exercise.

165	155	145	140	130	125	115	❤️
145	138	130	125	118	110	103	❤️
125	120	115	110	105	95	90	❤️
<hr/>							
20	30	40	50	60	70	80	

To find the proper intensity level, find your age at the bottom of the chart (ages are rounded off to the nearest ten years). The three numbers listed above your age define your “training zone.” The lowest number is the heart rate for fat burning, the middle number is the heart rate for maximum fat burning, and the highest number is the heart rate for aerobic exercise.

Burning Fat—To burn fat effectively, you must exercise at a low intensity level for a sustained period of time. During the first few minutes of exercise, your body uses carbohydrate calories for energy. Only after the first few minutes of exercise does your body begin to use stored fat calories for energy. If your goal is to burn fat, adjust the intensity of your exercise until your heart rate is near the lowest number in your training zone. For maximum fat burning, exercise with your heart rate near the middle number in your training zone.

Aerobic Exercise—If your goal is to strengthen your cardiovascular system, you must perform aerobic exercise, which is activity that requires large amounts of oxygen for prolonged periods of time. For aerobic exercise, adjust the intensity of your exercise until your heart rate is near the highest number in your training zone.

WORKOUT GUIDELINES

Warming Up—Start with 5 to 10 minutes of stretching and light exercise. A warm-up increases your body temperature, heart rate, and circulation in preparation for exercise.

Training Zone Exercise—Exercise for 20 to 30 minutes with your heart rate in your training zone. (During the first few weeks of your exercise program, do not keep your heart rate in your training zone for longer than 20 minutes.) Breathe regularly and deeply as you exercise; never hold your breath.

Cooling Down—Finish with 5 to 10 minutes of stretching. Stretching increases the flexibility of your muscles and helps to prevent post-exercise problems.

EXERCISE FREQUENCY

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

NOTES

PART LIST

Model No. FMEX82418.0 R0619A


Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Frame	51	2	M5 x 10mm Flat Head Screw
2	1	Drive Belt	52	1	Wear Cover
3	1	Generator	53	5	M5 x 10mm Nickel Screw
4	4	M6 x 15mm Flange Screw	54	1	Left Rear Cover
5	1	Control Board	55	1	Right Rear Shield
6	2	M5 x 10mm Screw	56	7	M4 x 16mm Screw
7	1	Pulley	57	1	Rear Shield Cover
8	1	Left Crank Arm	58	2	Shield Support
9	1	Right Crank Arm	59	2	M4 x 76mm Screw
10	4	M8 x 12mm Screw	60	1	Control Wire
11	2	T-bushing	61	1	Generator Wire
12	1	Crank	62	2	Coupler
13	2	M12 x 12mm Screw	63	1	Upper Power Wire
14	1	Bracket Sleeve	64	1	Lower Power Wire
15	1	Bracket Lock Ring	65	1	Ground Wire
16	1	Bracket Dust Cover	66	1	Upright
17	1	Pedal/Strap Set	67	1	Lower TV Coaxial Cable
18	1	Wiring Plate	68	1	Upper TV Coaxial Cable
19	1	Front Stabilizer	69	1	Lower Main Wire
20	1	Idler	70	1	Handlebar
21	1	M8 x 25mm Screw	71	2	Control Plate
22	3	M8 x 25mm Washer	72	1	Seat Plate
23	2	6204ZZ Bearing	73	4	Grip Plate
24	1	20mm C-clip	74	3	5/16" x 25mm Screw
25	1	Adjustment Hook	75	2	Control Switch
26	2	M6 Nut	76	2	M2 x 5mm Screw
27	1	Spring	77	8	M3 x 25mm Screw
28	2	Wheel	78	2	Keypad
29	2	M8 x 40mm Bolt	79	2	M6 x 13mm Washer
30	3	M8 Locknut	80	1	Handlebar Cap
31	4	Leveling Foot	81	1	Left Control Key Wire
32	4	M8 Nut	82	1	Right Control Key Wire
33	1	Battery	83	1	Pulse Sensor Wire
34	1	Adjustment Rod	84	1	Seat Post
35	1	Adjustment Handle	85	2	Pulse Grip
36	2	Plastic Sleeve	86	1	M5 Locknut
37	2	47mm Spacer	87	1	Adjustment Spring
38	2	M10 x 65mm Bolt	88	1	M6 Locknut
39	2	M16 Washer	89	4	M5 x 8mm Screw
40	2	M10 Locknut	90	2	Rod Pin
41	4	Stabilizer Cap	91	1	Seat
42	1	Upper Main Wire	92	2	Receptacle Plug
43	1	Idler Spacer	93	1	M5 x 45mm Screw
44	4	M8 x 25mm Patch Screw	94	1	M6 x 25mm Screw
45	12	M8 Split Washer	95	2	E-clip
46	2	Seat Post Sleeve	96	2	Bushing
47	1	Hook and Loop Fastener	97	1	Pivot Pin
48	1	M6 Washer	98	1	Front Upright Cover
49	2	M4 x 8mm Screw	99	1	Accessory Tray
50	1	Seat Post Cover	100	1	Rear Upright Cover

Key No.	Qty.	Description	Key No.	Qty.	Description
101	1	Left Front Shield	118	4	M4 x 12mm Self-tapping Screw
102	1	Right Front Shield	119	1	5/16" x 25mm Screw
103	1	Front Shield Cover	120	1	Tablet Shelf
104	4	Shield Clip	121	1	C-clip
105	1	Front Upright Cover Cap	122	1	Pulse Board
106	1	Console	123	4	Pulse Board Screw
107	4	M8 x 20mm Cap Screw	124	2	Handlebar Cap
108	4	M8 x 12mm Washer	125	1	USB Host Board
109	3	M8 x 25mm Cap Screw	126	1	Out 12" Board Wire
110	10	M8 x 16mm Washer	127	1	USB/Earphone Board
111	24	M5 x 12mm Screw	128	2	USB/Earphone Board Screw
112	1	Power Adapter/Wire	129	1	Ground Bar
113	1	Latch	130	1	20" Board Wire
114	1	Rear Stabilizer	131	1	In 12" Board Wire
115	1	C-SAFE Board	*	–	User's Manual
116	6	C-SAFE/USB Host Board Screw	*	–	Assembly Tool
117	1	Console Shelf			

Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. *These parts are not illustrated.


EXPLODED DRAWING A

Model No. FMEX82418.0 R0619A



EXPLODED DRAWING B

Model No. FMEX82418.0 R0619A



HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if parts are damaged or missing, please contact Customer Care at one of the phone numbers or addresses listed below. **Please note the model number, serial number, and name of the product (see the front cover of this manual) before contacting Customer Care. If you are ordering replacement parts, please also note the key number and description of each part (see the PART LIST and the EXPLODED DRAWING near the end of this manual).**

In the United States

Call: 1-800-201-2109, Mon.–Fri. 6 a.m.–6 p.m. MT

Email: customercare@freemotionfitness.com

Write:

Freemotion Fitness
1500 South 1000 West
Logan, UT 84321-9813
United States

Outside the United States

Call: 001-800-527-5417 or 001-435-786-3521,

Mon.–Fri. 6 a.m.–3 p.m. USA Mountain Time

Email: intlcustomercare@freemotionfitness.com

LIMITED WARRANTY

WARRANTY PERIODS AND COVERAGE

Freemotion Fitness warrants this product to be free from defects in workmanship and material under normal use and service conditions. Parts and labor are warranted for one (1) year, unless otherwise specified on the invoice.

The warranty period commences on the invoice date of purchase. Any parts repaired or replaced during this warranty period will be warranted for the remainder of the original warranty period.

CONDITIONS AND LIMITATIONS

The following will void the warranty on this product:

1. This warranty applies only to the original owner and is non-transferable.
2. The labor warranty applies only to products sold in the US and Canada. Contact your authorized Freemotion Fitness dealer for details on labor coverage in your country.
3. Any misuse, abuse, or improper service.
4. Users who weigh more than the maximum user weight listed in this manual.
5. Damage caused by moving the product or improper storage including moving or storing the product on its side.
6. Use or storage of the product outdoors or in high-humidity environments including spa and pool areas.
7. Damage caused by improper wiring or insufficient electrical current. Note: This product may not have wiring.

This warranty shall not apply to the following:

1. Cosmetic items including grips, decals, and labels.

2. Pick-up and delivery or freight charges involved with a repair.
3. Any problem as a result of improper assembly or delivery.

WHAT TO DO IF SERVICE IS REQUIRED

Freemotion Fitness warranty service may be obtained by contacting the authorized dealer from which you purchased this product. Make sure to retain your original invoice and serial number information. If this product experiences a failure under the warranty terms set forth, Freemotion Fitness shall provide at their option either repair, replacement, or refund of the purchase price. Freemotion Fitness compensates service providers for warranty trips within their service area. You may be charged additionally for service calls beyond this service area.

Freemotion Fitness is not responsible or liable for indirect, special, or consequential damages arising out of or in connection with the use or performance of the product; damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, or cost of removal or installation; or other consequential damages. Some regions do not allow the exclusion or limitation of consequential damages. Accordingly, the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights that vary from region to region.

TO CONTACT FREEMOTION FITNESS

See HOW TO CONTACT CUSTOMER CARE above.