

MARS SCREEN.

QUICK START GUIDE.

IMPORTANT INFORMATION.

YOUR SCREEN NEEDS TO ACCLIMATIZE TO YOUR ENVIRONMENT, SO ONCE YOU UNPACK IT, DON'T SWITCH IT ON FOR AT LEAST 2 HOURS.



MARS SCREEN.

QUICK START GUIDE.

1. CONNECT THE POWER CABLE.

STEP. 1

When unpacked you will see that the power socket is protected by a cover at the bottom rear of the screen. This is to ensure that the power is less likely to be accidentally disconnected and that the power cable is secure. First, the cover will need to be removed by unscrewing the two small screws holding the cover in place. These are not the screws shown below but the smaller screws used to fasten the cover. Once the cover is removed, insert one end of the power cable into socket shown below. Remember to re-fit the cover once the power cable is inserted and before the other end of the cable is plugged into a power source such as a wall socket. Ensure that the cable is not pulled or put under strain. The screen can then be connected to the power source.



2. POWER UP.

STEP. 2

Turn on the screen using the on/off power rocker switch on the left hand side of the unit as shown below. The rocker switch has a “I” and a “O”. When “I” is pressed down, the power is on and the unit will start when plugged in and power is present.



MARS SCREEN.

QUICK START GUIDE.


3. STEP. 3

CONNECT TO THE INTERNET.

For connection using a wired ethernet connection, insert one end of the ethernet cable into the port indicated in red below and the other end into the wall socket or internet router.



The network should provide an ip address and should provide access to the internet content server. If your network does not supply an address automatically and you want to connect using a wired connection then the address must be set manually. To do this press and hold the Escape logo at the bottom of the screen and then release. when doing this you will be asked to enter a passcode which is 2222.




MARS SCREEN.

QUICK START GUIDE.

After doing this you will be presented with a screen from the operating system where you will be able to manually switch from an automatically provided ip address to a static one instead.


FIRST SELECT “Ethernet”.



Then you will need to switch “ethernet ip mode” from “dhcp” to “static”




You will then be able to enter and save your ip settings to match your required settings manually like the example shown below.




MARS SCREEN.

QUICK START GUIDE.

For connection to the internet using a WiFi connection the wifi network and password need to be entered that match the available WiFi network. This is done in a similar way to that shown above. Firstly you will need to ensure that the three WiFi antennas are attached, screwed in fully and angled for the best possible reception.



To access the WiFi settings press and hold the Escape logo at the bottom of the screen and then release. When doing this you will be asked to enter a passcode which is 1111.



The following screen will then appear.

DISCONNECTED.

Select a network

Or connect the ethernet cable.

By pressing on the “select a network” box, you will be able select the network by which you want to connect the MARS screen to the internet followed by the WiFi pass code.

MARS SCREEN.

QUICK START GUIDE.

CUSTOMER SUPPORT.

If your screen doesn't start within 5 minutes, or you have any other concerns, please call our offices – +44 (0)1733 313535 (UK) or +1 614 706 4462 (USA) – quoting the details shown below 1-5. the serial number that can be found after holding down on the Escape logo at the bottom of the screen and pressing “1111”

YOU WILL BE ASKED THE FOLLOWING WHEN CALLING:

1. CONTACT NAME
2. INSTALLATION ADDRESS
3. CONTACT TELEPHONE NUMBER
4. EMAIL ADDRESS
5. SERIAL NUMBER OF THE UNIT

FULL INSTALLATION INSTRUCTIONS.

FOR YOUR FULL PACK OF INSTALLATION INSTRUCTIONS PLEASE VISIT:
escapefitness.com/user-guides/mars2-screen

4.

STEP 5

POWERING DOWN.

PLEASE NOTE. Do not simply unplug the power to switch off. the MARS screen must be shut down in the correct way to avoid damage. To do this press and hold the black button just above the rocker switch on the bottom left of the screen until a popup appears at the top right of the screen, then select shutdown. When the screen turn completely black then turn the rocker power switch to the off position.



FOR FURTHER INFORMATION INCLUDING REGULATORY INFORMATION AND TO REGISTER YOUR PRODUCT TO OBTAIN WARRANTY VISIT.
[escape fitness.com/user-guides/mars-screen](https://escapefitness.com/user-guides/mars-screen)

WE HOPE YOU ENJOY YOUR MARS SCREEN!